

Technical Information



Software update Gear Tronic II

A new software version (version: 1.069) for the Gear Tronic II device is now available. The following improvements have been implemented into the software:

- the vehicle database has been updated
- additional languages have been added (Hungarian and Romanian)
- specifications of automatic transmission oils have been updated
- new automatic transmission oils have been added
- type of automatic transmission oil has been added to printing options
- printer settings have been optimized

To ensure optimal and trouble-free operation of the device, please install the software updates provided by us on a regular basis.

Note: For vehicles with gear oil thermostats, be sure to flush the gear oil only after the thermostat has opened. The inlet and outlet pressure of the Gear Tronic II should be taken into account here. The pressures should be almost the same.

Below you will see how to install the new software:

Download

The new software can be downloaded via

<https://www.liqui-moly.com/en/service/gear-tronic-instructions.html>

liqui-moly.com/en/service/gear-tronic-instructions.html

LIQUI MOLY Motor oils, additives, vehicle maintenance ... Oil guide Where to buy

Company Products Areas of use Sales Partners Press Contact

Gear Tronic instructions

Determine vehicle brand and model

Select brand Select model

Softwareupdate Gear Tronic II (V 1.069) (ZIP, 19 MB) ZIP Nexus Print Software (ZIP, 38 MB) EXE

Technical Information



Data transfer

1. Unpack the ZIP compressed files.
2. Copy the unpacked folder "ATX" to an empty USB stick (FAT32 formatted) with a maximum of 3 GB memory.

Installing the update

1. Switch off your Gear Tronic II device.
2. Connect the USB stick on the back of the device to the corresponding USB port.
3. Switch your Gear Tronic II device on again.
4. Confirm on the screen that you want to start the update.
5. Please do not switch off your device as long as the software update is being installed. The screen turns completely black for a few seconds during the update. Please wait until the screen returns to the main menu.
6. You can then remove the USB stick. The software is now up to date.